

LOUI -- DeVeney

		Instruments			
		Instrumentation Main Page			
		<u>Facility Instruments:</u>			
Quick Links	LDT Observer Information Home		Large Monolithic Imager (LMI)		
	Instrumentation	Facility	DeVeney Optical Spectrograph	Observing Planning	
	Applying for Observing Time	LDT Science Schedule	NIR Spectrograph (NIHTS)	Applying for Observing Time	
	Observing Run Planning	LDT Staff	<hr/> <u>Visitor / PI Instruments:</u> <hr/> High-Res Spectrograph (EXPRES) Speckle Imager (QWSSI) High Speed Imager (POETS) <hr/> NIR Spectrograph (RIMAS) <hr/> <u>User Manuals:</u> LMI Manual DeVeney Manual NIHTS Manual	Planning Checklist	
	At the Telescope (Printable Logsheets)	Telescope		Remote Observing	Target of Opportunity (ToO Policies)
	Target of Opportunity (ToO) Policies	Site Information		Target of Opportunity (ToO) Policies	Remote Observing
	After Your Observing Run	Weather		Target Lists	LDT Startup Procedures
	First-Time Users	Acknowledging LDT		First-Time Users	Closure Conditions
	Logistics	Selected Technical Publications		Logistics	Night Feedback Form
					End of Night Tasks
	LDT Important Notes				




The user manual can be found on the main [Observing at DCT](#) page, under the Instruments section.

An introductory video generated for LMI can be useful for DeVeney users as well: [LMI_LOUI_720.mov](#) (it would be best to download this video for viewing)

The DeVeney LOUI is the only way observers can interact with the spectrometer. There is an IDL GUI for using the slit viewing camera which is described else where. Unlike previous versions of LOIS, an observer cannot access the LOIS command line and run commands or scripts on LOIS directly. These pages will describe all the components of the UI and are not meant as a cookbook or an operations manual but rather as a reference for more detailed information of the available functions.

It may be useful for the observer to have some understanding of the underlying architecture of the software systems and links will be provided as different components are mentioned. The DeVeney LOUI is an [Eclipse](#) based [RCP](#) (Rich Client Platform) application which is the front end (user interface) to the instrument and its data acquisition software (LOIS).

An RCP application has a workspace which is composed of one or more perspectives. Each perspective is composed of editors and views. A view encapsulates a unique function, such as camera control or Facility Summary, and is generally composed of many widgets which allow display of information or data input. The DeVeney LOUI has a main perspective referred to as Dashboard which contains all the views necessary for camera control and data acquisition. On start up, the DeVeney LOUI's Dashboard will look like this:



The initial configuration is hard coded but there is a lot of flexibility in arranging the views and it is recommended that the observers play around with this functionality to become more familiar with it. A user should not be concerned about re-arranging, minimizing or maximizing the views. If at any time the UI gets to a state where things look very strange, one can always go back to the initial configuration by using Window Reset Perspective command from the main application menu bar:

[blocked URL](#)

We'll start with a review of the layout of the Dashboard and then will go into the details of the individual components. Please remember that this is not meant as a set of instructions on how to take data with DeVeney but rather a detailed description of the available functions so the astronomers will have a more efficient interaction with the instrument.

- [Workspace Layout](#)
- [Dashboard - Upper Left Pane](#)
- [Dashboard - Upper Right Pane](#)
- [Dashboard - Console Pane](#)
- [Dashboard - Info Pane](#)
- [Developer Perspective](#)